



Note: All connectors are numbered left to right facing the Power Panel NOT THE MEADE PUBLISHED PIN ORDER.

Note: All connectors are numbered left to right facing the Power Panel NOT THE MEADE PUBLISHED PIN ORDER.

Note: Replace C1 or C3 with 6.8 uF 35V Tantalum Capacitors

TelescopeService.com		
Title MEADE LX200 Classic - Power Panel		
Size B	Document Number 834-2000	Rev B
Date: Saturday, May 21, 2005	Sheet 1	of 1